



Crown Drapery Valance Installation Instructions

- A. SpecTrim® Pre-finished Drapery Valances should be placed in the installation area 48 hours prior to installing to adjust to the climate of the room.
- B. Examine wall conditions before beginning installation of SpecTrim® Drapery Valances. Verify dimensions and acceptability of wall conditions. Do not proceed with installation of SpecTrim® products until unacceptable wall conditions have been corrected.
- C. Inspect each SpecTrim® Pre-finished Drapery Valance prior to installing. Do not install defective or damaged Valances.
- D. Install SpecTrim® Pre-finished Drapery Valance using a panel adhesive suitable for use on wood moldings to adhere to wall surfaces, and screws to attach to wall framing at ceiling. If Valance is to be installed lower than the Ceiling Ht., obtain a suitable valance mounting bracket and screw or anchor bracket to wall face using screws or anchors for your specific wall condition. Also screw attach bracket to the plywood Valance top panel.
- E. Clean Pre-finished SpecTrim® Drapery Valances using denatured alcohol. Do not use abrasives on PVC surface.
- F. Maintenance
- Caulking**
Use non-marking masking tape along both sides of a colored caulk joint to create a clean narrow bead.
- Repairing Cuts in PVC**
Superficial surface scratches should be cleaned with denatured alcohol and fill with matching wax putty. Excess wax is removed and smoothed using a soft cloth dipped in Naptha solvent.
- Repairing Dents in Molding**
Cut away damaged or misshapen surface and clean area to be patched. Use either wax putty or colored caulk to fill following the clean-up procedures listed above. If damage is too severe making molding either structurally or aesthetically unacceptable, remove and replace Valance.